




Fuel Pressure Relieving

Before disconnecting fuel lines or hoses, release pressure from the system by loosening the fuel pulsation damper on top of the fuel rail.

1. Make sure you have the anti-theft code for the radio, then write down the frequencies for the radio's preset buttons.
2. Disconnect the negative cable from the battery.
3. Remove the fuel fill cap.
4. Use a wrench on the fuel pulsation damper (A) at the fuel rail.



5. Place a rag or shop towel (B) over the fuel pulsation damper.
6. Slowly loosen the fuel pulsation damper one complete turn.


NOTE: Replace all washers whenever the fuel pulsation damper is loosened or removed.

Fuel Pressure Test


Special Tools Required

- Fuel pressure gauge 07406-0040001
- Fuel pressure gauge attachment 07VAJ-0040100

1. Relieve the fuel pressure.
2. Use a wrench to remove the fuel pulsation damper from its fitting, then attach the fuel pressure gauge attachment.



3. Attach the fuel pressure gauge.



4. Disconnect the vacuum hose (A) from the fuel pressure regulator (B) and pinch it closed with a clamp (C).

(cont'd)

Fuel Supply System

Fuel Pressure Test (cont'd)

5. Start the engine and let it idle.
 - If the engine starts, go to step 7.
 - If the engine does not start, go to step 6.
6. Check to see if the fuel pump is running: remove the fuel fill cap and listen to the fuel fill port while an assistant turns the ignition switch ON (II). You should hear the pump run for about 2 seconds when the ignition is turned ON (II).
 - If the fuel pump runs, go to step 7.
 - If the fuel pump does not run, test it (see page 11-117).
7. Read the pressure gauge (with the fuel pressure regulator vacuum hose disconnected and clamped). The pressure should be 320–370 kPa (3.3–3.8 kgf/cm², 47–54 psi).
 - If the pressure is OK and engine is running, go to step 8. If the engine is not running, repair the cause, then continue this test.
 - If the pressure is out of spec, go to step 9.
8. With the engine running, unpinch and reconnect the vacuum hose, and read the gauge again. The pressure should be 260–310 kPa (2.7–3.2 kgf/cm², 38–46 psi).
 - If the fuel pressure is OK, the test is complete.
 - If the pressure is out of spec, go to step 9.
9. Disconnect the vacuum hose from the pressure regulator again while you watch the pressure gauge. The pressure should rise when you disconnect the hose.
 - If the pressure did not rise, replace the fuel pressure regulator (see page 11-123).
 - If the pressure rose, but all your readings were lower than specified, check for a clogged fuel filter and for leaks in the fuel lines.
 - If the pressure rose, but all your readings were higher than specified, check for a pinched or clogged fuel return hose or line.
10. Reconnect the vacuum hose, remove the pressure gauge, and reinstall the fuel pulsation damper with a new washer. Tighten the fuel pulsation damper to 22 N·m (2.2kgf·m, 16 lbf·ft).

NOTE: Disassemble and clean the fuel pressure gauge attachment thoroughly after use.