Component Locations

NOTE: LHD type is shown. RHD is similar.

ENGINE CONTROL
MODULE (ECM)

AUTOMATIC TRANSAXLE (A/T)
GEAR POSITION SWITCH

BRAKE SWITCH

TRANSMISSION CONTROL
MODULE (TCM)

THROTTLE POSITION (TP)
SENSOR

VEHICLE SPEED
SENSOR (VSS)

ENGINE COOLANT
TEMPERATURE (ECT) SENSOR

COUNTERSHAFT
SPEED SENSOR

MAINSHAFT
SPEED SENSOR

SHIFT CONTROL SOLENOID
VALVE ASSEMBLY

LOCK-UP CONTROL SOLENOID
VALVE ASSEMBLY